




29111 Stephenson Hwy.  
Madison Heights, MI 48071 USA  
800-626-6653

## JIFFY-MATIC SEAL REMOVAL KIT



### SEAL REMOVAL

1. Attach appropriate sized tool to threaded end of tool handle. Use of protective gloves is recommended due to sharp edge of tool.
2. Insert tool into socket and turn handle 1/2 to 3/4 of a turn.
3. Remove tool and seal from socket. If seal is not completely captured by tool it may remain partially lodged in socket. The seal pick provided can be used to remove the seal if this occurs.

### INSERTING A NEW SEAL

1. Place seal squarely into socket, flush with socket end.
2. Use any mating Jiffy-Tite plug to push seal into position.